


VINTAGE DELAY VD400

Vintage Analog Delay Effects Pedal

Thank you for showing your confidence in us by purchasing the BEHRINGER VINTAGE DELAY VD400. This ultimate effects pedal is designed to deliver amazing delay sounds comparable to state-of-the-art studio processors. Thanks to its parameter controls, you'll have plenty of cool sounds at your disposal to handle almost any situation.

The delay effect creates a delay of the input signal with various repetitions. Different tempo settings allow interesting delay effects.

1. Controls



- 1 The **REPEAT RATE** control adjusts the delay time (repetition rate).
- 2 The **ECHO** control adjusts the effect output level.
- 3 The **INTENSITY** control adjusts the number of repetitions.
- 4 The **ON/BATT** LED illuminates when the effect is activated. It also serves as a battery level indicator.
- 5 Use the footswitch to activate/deactivate the effect.
- 6 Use this 1/4" TS **IN** connector to plug in the instrument cable.
- 7 The 1/4" TS **OUT** connector sends the signal to your amp.
- 8 The 1/4" TS **DIR OUT** connector sends the unaffected signal to connect, for example, to a separate amp.

◆ If you use the **OUT** connector only, it will send the affected signal and, when deactivated, the unaffected signal. When using both the **OUT** and the **DIR OUT**, the VD400 acts like an A/B box. This means when activated, the **OUT** sends only the echo signal while the **DIR OUT** carries the dry signal. When deactivated the **OUT** is muted while the **DIR OUT** sends the unaffected signal.

Use the **DC IN** connection to plug in a 9 V power supply (not included).

The **BATTERY COMPARTMENT** is located underneath the pedal cover. To install or replace the 9 V battery (not included), press the hinges with a ballpoint pen and remove the pedal cover. Be careful not to scratch the unit.

♦ **The VD400 has no on/off switch. As soon as you insert the plug into the in connector, the VD400 is on. When not in use, remove the plug from the in connector. This extends the life of the battery.**

The **SERIAL NUMBER** is located at the underside.

2. Safety Instructions

Do not use near water, or install near heat sources. Use only authorized attachments/accessories. Do not service product yourself. Contact our qualified servicing personnel for servicing or repairs, especially when power supply cord or plug is damaged.

3. Warranty

Please register your new BEHRINGER equipment right after your purchase by visiting <http://behringer.com> and read the terms and conditions of our warranty carefully.

4. Specifications

In	
Connector	¼" TS
Impedance	500 kΩ

Out	
Connector	¼" TS
Impedance	1 kΩ

Power Supply	
	9 V DC , 100 mA regulated

BEHRINGER PSU-BB

USA/Canada	120 V~, 60 Hz
Europe/U.K./Australia	230 V~, 50 Hz
China	220 V~, 50 Hz
Korea	220 V~, 60 Hz
Japan	100 V~, 50/60 Hz

Power connector	2 mm DC jack, negative center
Battery	9 V type 6LR61
Power consumption	30 mA

Physical/Weight	
Dimensions (H x W x D)	approx. 2 ⅛ x 2 ¾ x 4 ⅜"
	approx. 54 x 70 x 123 mm
Weight	approx. 0.73 lbs / 0.33 kg

BEHRINGER is constantly striving to maintain the highest professional standards. As a result of these efforts, modifications may be made from time to time to existing products without prior notice. Specifications and appearance may therefore differ from those listed or shown.

TECHNICAL SPECIFICATIONS AND APPEARANCES ARE SUBJECT TO CHANGE WITHOUT NOTICE AND ACCURACY IS NOT GUARANTEED. BEHRINGER IS PART OF THE MUSIC GROUP (MUSIC-GROUP.COM). ALL TRADEMARKS ARE THE PROPERTY OF THEIR RESPECTIVE OWNERS. MUSIC GROUP ACCEPTS NO LIABILITY FOR ANY LOSS WHICH MAY BE SUFFERED BY ANY PERSON WHO RELIES EITHER WHOLLY OR IN PART UPON ANY DESCRIPTION, PHOTOGRAPH OR STATEMENT CONTAINED HEREIN. COLORS AND SPECIFICATIONS MAY VARY FROM ACTUAL PRODUCT. MUSIC GROUP PRODUCTS ARE SOLD THROUGH AUTHORIZED FULLFILLERS AND RESELLERS ONLY. FULLFILLERS AND RESELLERS ARE NOT AGENTS OF MUSIC GROUP AND HAVE ABSOLUTELY NO AUTHORITY TO BIND MUSIC GROUP BY ANY EXPRESS OR IMPLIED UNDERTAKING OR REPRESENTATION. THIS MANUAL IS COPYRIGHTED. NO PART OF THIS MANUAL MAY BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING AND RECORDING OF ANY KIND, FOR ANY PURPOSE, WITHOUT THE EXPRESS WRITTEN PERMISSION OF MUSIC GROUP IP LTD. ALL RIGHTS RESERVED. © 2012 MUSIC Group IP Ltd. Trident Chambers, Wickhams Cay, P.O. Box 146, Road Town, Tortola, British Virgin Islands